



**MOOSE RUBBERROLL**  
**RECYCLED RUBBER CARE & MAINTENANCE GUIDE**  
**Revised 06-02-09**

The MOOSE RUBBERROLL recycled rubber flooring, like all quality floor surfaces, requires consistent cleaning and scheduled maintenance to ensure that it stays looking great. The schedule for cleaning depends on many factors including – various activities, how often the floor is used, and the volume of foot traffic on the floor. The more consistent the cleaning schedule, the better the appearance of the floor. The following general guidelines will help to keep your new MOOSE RUBBERROLL floor looking great.

- 1) Do NOT wash floor for at least five (5 days) after installation.
- 2) Initial Cleaning  
Remove all surface soil, debris, sand, and grit by sweeping, dust mopping, or vacuuming with a high CFM vacuum. For large areas, use auto scrubbers to clean floors. Scrub floor with a neutral pH (7-9) detergent, such as TASKI PROFI cleaner (10 oz./gal. of water), using buffer or auto scrubber with a soft nylon brush or purple pad. Avoid flooding the floor. Pick up solution with a wet vacuum, rinse with clean water, picking up the rinse water with a wet vacuum and allow to dry thoroughly (6-8 hours).
- 3) Daily/Regular Cleaning  
Sweep, dust mop, or vacuum floor to remove surface soil, debris, sand, and grit. . Damp mop with a microfiber mop or auto- scrub using TASKI mint pad or nylon brush with TASKI PROFI (6-10 oz./gal. of water) or equivalent pH neutral cleaner.
- 4) Restorative Maintenance  
Sweep and dry vacuum floor thoroughly. Heavy scrub floor with TASKI PROFI (10 oz./gal. of water) or TASKI ice-it. This cleaning may be performed with an auto scrubber or rotary scrubber (TASKI purple or black pad). Vacuum soiled solution with a wet/dry vacuum. Rinse with clean water. Pick up solution with wet vacuum. Allow floor to thoroughly dry
- 5) Heavy Soil  
Remove as much surface soil, debris, sand, and grit as possible by sweeping, dust mopping, or vacuuming. Scrub floor with a neutral pH (7-9) detergent, such as TASKI PROFI cleaner or TASKI ice it stripper, using a buffer or auto scrubber with a TASKI black pad. Pick up solution with a wet vacuum, rinse with clean water and allow to dry thoroughly (6-8 hours).
- 6) Walk-off mats must be used at all doorways and openings to clean abrasive grit and contaminants from shoes.
- 7) Do not use spikes on your MOOSE RUBBERROLL floor.
- 8) When using Johnson-Diversey maintenance products, please contact the manufacturer directly for complete information at 800-827-5427, x130. A local representative will be glad to thoroughly explain and demonstrate the product use and application.